

Trying to reach timeserver from Network-startup

[Roadshow Support](#) -> [Trying to reach timeserver from Network-startup](#)

JohnFante

#1/1 Verfasst am: 24.08.2019 - 09:56 Titel: Trying to reach timeserver from Network-startup

I am trying to set my internal clock (do not have hardware RTC) via the network-startup file but can not get it to work.

I have added:

Code:

```
WAIT 50  
Run >NIL: C: rentp -o120 0.dk.pool.ntp.org
```

after

AddNetInterface DEVS:NetInterface ... and so on in the Network-Startup file. I have seen that done that way elsewhere.

Previously I had the rentp command in my startup-sequence (without the wait) but I have added a Vampire (🧛) to my A600 and it simply runs too fast for the network to initialise probably before the OS starts up. That gave me some intuition errors that I solved by adding a Run >NIL: before the Execute S:Network-Startup to let it run its cause seperately.

Any suggestions to how I can pull time from a timeserver via the Network-Startup file so that internet is up and running before I pull the time?[/code]